

FAGOR AUTOMATION S.COOP.

Brushless AC
Servo Drives
~ **MCSi-S0 series** ~

Ref.1504





FAGOR 



14460069

Original instructions

Title	Brushless AC servo drives. MCSi-S0 series.
Type of documentation	Description, installation and startup of motors and digital drives MCS INNOVA with SERCOS interface.
Name	MAN REGUL MCSi-So (IN)
Manual reference	Ref.1504
Software	Version 01.0x
Electronic document	man_mcsi_s0.pdf
Headquarters	Fagor Automation S.Coop. B.º San Andrés 19, apdo. 144 20500 ARRASATE-MONDRAGÓN Gipuzkoa (Spain) www.fagorautomation.com info@fagorautomation.es
	 +34 943 719200
	 +34 943 771118 (SAT)

DUAL-USE products. Products manufactured by Fagor Automation S. Coop. included on the list of dual-use products according to regulation (UE) Nr 1382/2014. Their product identification includes the text -MDU and require an export license depending on destination.

All rights reserved. No part of this documentation may be copied, transmitted, transcribed, stored in a backup device or translated into another language without Fagor Automation's permission.



Responsibility exemption

The information described in this manual may be subject to changes due to technical modifications. Fagor Automation S. Coop. reserves the right to change the contents of this manual without prior notice.

The content of this manual and its validity for the product described here has been verified. Nevertheless, the information, technical or otherwise, in these manuals or in any other type of documentation is not guaranteed to be integral, sufficient or up to date.

Involuntary errors are possible, hence the absolute match is guaranteed. However, the contents of manuals and documents are regularly checked and updated implementing the pertinent corrections in later editions.

Fagor Automation S. Coop. will not be held responsible for any losses or damage, direct, indirect or by chance that could result from that information and it will be the user's responsibility to use it.

Responsibility and warranty claims are excluded in case of shipping damage, wrong usage of the unit in wrong environments or when not used for the purpose for which it has been designed, ignoring the warnings and safety indications given in this document and/or legal ones that may be applied to the work place, software modifications and/or repairs made by unauthorized personnel, damage caused by the influence of other nearby equipment.

Warranty

The warranty terms may be requested from your Fagor Automation representative or through the usual commercial channels.

Registered trademarks

All registered trade marks, even those not indicated are also acknowledged. When some are not indicated, it does not mean that they are free.

April 2015 / Ref.1504

Warranty

Initial warranty

All products manufactured or marketed by FAGOR carry a 12-month warranty for the end user.

In order to prevent the possibility of having the time period from the time a product leaves our warehouse until the end user actually receives it run against this 12-month warranty, the OEM or distributor must communicate to FAGOR the destination, identification and installation date of the machine by filling out the Warranty Form that comes with each product.

The starting date of the warranty for the user will be the one appearing as the installation date of the machine on the Warranty Form.

This system ensures the 12-month warranty period for the user.

FAGOR offers a 12-month period for the OEM or distributor for selling and installing the product. This means that the warranty starting date may be up to one year after the product has left our warehouse so long as the warranty control sheet has been sent back to us. This translates into the extension of warranty period to two years since the product left our warehouse. If this sheet has not been sent to us, the warranty period ends 15 months from when the product left our warehouse.

FAGOR is committed to repairing or replacing its products from the time when the first such product was launched up to 8 years after such product has disappeared from the product catalog.

It is entirely up to FAGOR to determine whether a repair is to be considered under warranty.

Excluding clauses

The repair will take place at our facilities. Therefore, all shipping expenses as well as travelling expenses incurred by technical personnel are NOT under warranty even when the unit is under warranty.

The warranty will be applied so long as the equipment has been installed according to the instructions, it has not been mistreated or damaged by accident or negligence and has been handled by personnel authorized by FAGOR.

If once the service call or repair has been completed, the cause of the failure is not to be blamed on the FAGOR product, the customer must cover all generated expenses according to current fees.

No other implicit or explicit warranty is covered and FAGOR AUTOMATION shall not be held responsible, under any circumstances, of the damage which could be originated.

Service contracts

Service and Maintenance Contracts are available for the customer within the warranty period as well as outside of it.

Declaration of conformity

Manufacturer: Fagor Automation, S. Coop.
B.º San Andrés 19, C.P. 20500, Mondragón - Gipuzkoa - (SPAIN)

We hereby declare, under our responsibility that the product:

FAGOR AC Brushless Servo Drive System

consisting of the following modules and motors:


Drive modules MCS Innova MCSi-S0 series

AC motors FS. FSA and FSP series

mentioned on this declaration,

with the basic requirements of the European Directives 2006/95/EC on Low Voltage (Basic Safety Regulation; Machinery Electrical Equipment EN 60204-1:2006) and 2004/108/EC on Electromagnetic Compatibility (EN 61800-3:2004, Specific Regulation on Electromagnetic Compatibility for Servo Drive System).

Fagor Automation, S. Coop.


Director Gerente
Pedro Ruiz de Aguirre

In Mondragón, July 1st, 2009

Introduction

FAGOR offers a range of servo systems (AC brushless motor FS plus digital drive) for application between 0.318 and 2.39 N·m at a rated speed of 3000 rev/min.

This manual describes the elements in detail and guides step by step through the installation and setup of the drive system.

When installed for the first time, it is a good idea to read the whole document.

Should you have any doubts or questions, please do not hesitate to contact our technicians at any of our subsidiaries worldwide.

Thank you for choosing FAGOR.

General index

- BRUSHLESS AC MOTORS, FS. 7**
- Introduction 7
- General characteristics 7
- Synchronous AC servomotors FSP series 9
- Dimensions 10
- Connectors 12
- Holding brake 13
- Sales model 14

- MCSi-S0 SERVODRIVE 15**
- Introduction 15
- General characteristics 15
- Dimensions 15
- Technical data 16
- Connectors 16
- Indicators 18
- Push-buttons and switches 19
- Front view 19
- Top view 20
- Pinout of the connectors 20
- Sales model 22

- INSTALLATION 23**
- General considerations 23
- Electrical connections 24
- Diagram of the electrical cabinet 36
- Safety. Safe Disable 37
- Initialization and adjustment 39

- PARAMETERS, VARIABLES & COMMANDS 42**
- Notation used 42
- A group. Application 44
- B group. Non-programmable inputs-outputs 44
- C group. Current 45
- D group. Diagnosis 47
- G group. General 50
- H group. Hardware 52

I group. Inputs	52
K group. Monitoring	53
M group. Motor	54
N group. Mechanical	55
O group. Analog and digital outputs	56
P group. Position loop	57
Q group. Communication	60
S group. Velocity	61
T group. Torque and power	64
ERROR CODES	65
LIST OF PARAMETERS, VARIABLES & COMMANDS.	
SERCOS ID's	70

BRUSHLESS AC MOTORS, FS

Introduction

FS synchronous servo motors (FSA and FSP series) are AC Brushless with permanent magnets.

They are ideal for any application requiring great positioning accuracy.

They have a uniform output torque, high reliability and low maintenance.



General characteristics

TABLE 1. General characteristics of FS motors.

Excitation	Permanent magnets
Temperature sensor	Not available
Shaft end	Cylindrical with keyway (optional: without keyway)
Mounting	Face flange
Mounting method	IM B5, IM V1, IM V3 (as per IEC-34-3-72)
Mechanical tolerances	Eccentricity: 0.02 Concentricity: 0.04 Perpendicularity: 0.04
Roller bearings' life	20000 hours
Vibration resistance	Vibration acceleration: 49 m/s ²
Vibration class	15 µm or lower
Electrical insulation	Class B (130 °C / 266 °F)
Insulation resistance	500 V DC, 10 MΩ or greater
Dielectric rigidity	200 V motors: 1500 V AC, one minute
Body or housing	Totally enclosed and self-ventilated
Protection degree	General: standard IP 55 (shaft section excluded)
Storage temperature	From - 20 °C to 60 °C (- 4 °F to 140 °F)
Ambient temperature allowed	From 0 °C to 40 °C (from 32 °F to 104 °F)
Working ambient humidity	From 20 % to 80 % (non condensing)
Voltage supply for the brake	24 V DC - the brake is optional -
Feedback	Standard: Incremental encoder 13 bits: 2028 ppt Optional: Absolute encoder 16 bits: 16384 ppt

TABLE 2. Characteristics table of non-ventilated FSA/FSP motors with “F” winding (220 V AC).

FSA SERIES	Stall torque		Rated speed nN rev/min	Maximum speed nmax rev/min	Stall current Io Arms	Peak current Ip Arms	Power P W	Torque constant Kt Nm/Arms	Acceleration time tac ms	Inertia ¹ J kg·cm ²	Mass ² M kg	Peak torque (for 3 seconds)		
	Mo Nm	Mp Nm										MCSi -07L-S0 Nm	MCSi -11L-S0 Nm	MCSi -15L-S0 Nm
FSA01.50F.□□.□□□□	0.318	0.95	3000	5000	0.9	2.8	100	0.378	1.19	0.036	0.5	0.95		
FSA02.50F.□□.□□□□	0.637	1.91	3000	5000	2.1	6.5	200	0.327	1.74	0.106	1.1	1.91		
FSA04.50F.□□.□□□□	1.27	3.82	3000	5000	2.8	8.5	400	0.498	1.42	0.173	1.7	3.24	3.82	
FSA08.50F.□□.□□□□	2.39	7.16	3000	5000	4.4	13.4	750	0.590	2.95	0.672	3.4	3.84	6.19	7.16

FSP SERIES	Stall torque		Rated speed nN rev/min	Maximum speed nmax rev/min	Stall current Io Arms	Peak current Ip Arms	Power P W	Torque constant Kt Nm/Arms	Acceleration time tac ms	Inertia ¹ J kg·cm ²	Mass ² M kg	Peak torque (for 3 seconds)		
	Mo Nm	Mp Nm										MCSi -07L-S0 Nm	MCSi -11L-S0 Nm	MCSi -15L-S0 Nm
FSP01.50F.□□.□□□□	0.318	0.95	3.000	5.000	0.9	2.8	100	0.392	1.62	0.491	0.7	0.95		
FSP02.50F.□□.□□□□	0.637	1.91	3.000	5.000	2.0	6.0	200	0.349	3.17	0.193	1.4	1.91		
FSP04.50F.□□.□□□□	1.27	3.82	3.000	5.000	2.6	8.0	400	0.535	2.72	0.331	2.1	3.48	3.82	
FSP08.50F.□□.□□□□	2.39	7.16	3.000	5.000	4.1	13.9	750	0.641	9.21	2.100	4.2	4.17	6.73	7.16


1] If the motor has a brake (option), its inertia must also be taken into account. See «brake characteristics».

2] If the motor has a brake (option), its mass must also be taken into account. See «brake characteristics».


Note. The drive recommended to govern each motor must supply the rated current needed to obtain the rated torque from the motor.

Torque-speed curves

Synchronous AC servomotors FSA series



Synchronous AC servomotors FSP series



Dimensions

Synchronous AC servomotors. FSA series




FIGURE 1

Dimensions of FSA series synchronous servo motors.

TABLE 3. Motor. Dimensions in mm.

Dimensions	Motor length				LR	Flange surface					
	LM	L	LL	Δ brake		LA	LB	L	LE	LG	LZ
FSA01	61.5	119.5	94.5	40.5	25	46	30h	40	2.5	5	4.3
FSA02	63.0	126.5	96.5	39.5	30	70	50h	60	3	6	5.5
FSA04	91.0	154.5	124.5	39.5	30	70	50h	60	3	6	5.5
FSA08	111.5	185.0	145.0	44.5	40	90	70h	80	3	8	7.0

The «Δ brake» column shows the length increment for the L and LL measurements when using a motor configuration "with brake".

TABLE 4. Shaft. Dimensions in mm.

Dimensions	Shaft end					Shaft hole
	S	QK	W	T	V	
FSA01	8h6	14	3	3	9.2	M3 x 6
FSA02	14h6	20	5	5	16	M5 x 8
FSA04	14h6	20	5	5	16	M5 x 8
FSA08	16h6	30	5	5	18	M5 x 8

Synchronous AC servomotors. FSP series




FIGURE 2

Dimensions of FSP series synchronous servo motors.

TABLE 5. Motor. Dimensions in mm.

Dimensions	Motor length					Flange surface					
	LM	L	LL	Δ	LR	LA	LB	LC	LE	LG	LZ
FSP01	42.5	87	62	29.0	25	70	50h7	60	3	6	5.5
FSP02	48.1	97	67	31.5	30	90	70h7	80	3	8	7
FSP04	68.1	117	87	31.5	30	90	70h7	80	3	8	7
FSP08	66.7	126.5	86.5	33.5	40	14	110h	12	3.5	10	10

The « Δ brake» column shows the length increment for the L and LL measurements when using a motor configuration "with brake".

TABLE 6. Shaft. Dimensions in mm.

Dimensions	Shaft end					Shaft hole
	S	QK	W	T	V	
FSP01	8h6	14	3	3	9.2	M3 x 6
FSP02	14h6	16	5	5	16	M5 x 8
FSP04	14h6	16	5	5	16	M5 x 8
FSP08	16h6	22	5	5	18	M5 x 8

Connectors

Power connector

The following figure shows the identification of these connectors:




FIGURE 3

Power and feedback connector.

Note that although the figure shows the FSA series motor, the dimensions of all the connectors will be the same for the FSP series.

The base power connector includes pins 4 and 5 of the brake. Remember that it has no polarity and, therefore, the 24 V DC may be applied to either pin. A voltage between 22 V DC and 26 V DC applied to the brake releases the shaft .

When installing the motor, verify that the brake releases the shaft completely before turning it for the first time.

Connecting the motor windings in the order indicated on the connector (U, V, W) of the figure below, the shaft will turn clockwise (CWR, clockwise rotation).




FIGURE 4

Power base connector pinout.

Encoder output




FIGURE 5

Feedback base connector pinout.

Holding brake

FSA and FSP series motors have an optional brake that applies friction to the shaft. Its purpose is to immobilize or lock vertical axes, **not to brake a moving axis**.



WARNING. NEVER use this brake to stop a moving axis !

Its main characteristics depending on the type of brake are:

TABLE 7. Technical characteristics of the brake.

Brake	Holding torque	Power consumption	Supply voltage	Inertia	Mass
	N·m (lbf·in)	W (hp)	V DC	kg·cm ²	kg (lbf)
FSA01	0.318 (2.814)	6.0 (0.008)	24	0.0085	0.300 (0.66)
FSA02	0.637 (5.637)	6.9 (0.009)	24	0.058	0.500 (1.10)
FSA04	1.270 (11.240)	6.9 (0.009)	24	0.058	0.500 (1.10)
FSA08	2.390 (21.153)	7.7 (0.010)	24	0.058	0.900 (1.98)
FSP01	0.318 (2.814)	8.1 (0.010)	24	0.029	0.200 (0.44)
FSP02	0.637 (5.637)	7.6 (0.010)	24	0.109	0.500 (1.10)
FSP04	1.270 (11.240)	7.6 (0.010)	24	0.109	0.500 (1.10)
FSP08	2.390 (21.153)	7.5 (0.010)	24	0.875	1.500 (33.1)

WARNING.



- ❑ The brake must never exceed its maximum turning speed.
- ❑ A voltage between 22 V DC and 26 V DC releases the shaft from being locked up. Make sure that no voltage over 26 V DC is applied that prevents the shaft from turning.
- ❑ When installing the motor, make sure that the brake fully releases the shaft before making it turn for the first time.

Sales model

FSA04.50F.J5.000 - S99

MOTOR SERIES

MOTOR LENGTH
 LONG MOTORS **A**
 SHORT MOTORS **P**

SIZE/POWER

HEIGHT	FSA		FSP	
	200 V	kW	200 V	kW
40	01	0.1		
60			01	0.1
	02	0.2		
80	04	0.4		
			02	0.2
			04	0.4
	08	0.75		
120			08	0.75

MAXIMUM SPEED
50 5000 rev/min
 Note that the rated speed is 3000 rev/min

VOLTAGE
 200 V **F**

FEEDBACK
 13 bit incremental **J5**
 16 bit absolute **J7**

FLANGE & SHAFT
 Cylindrical shaft with keyway and tapped hole **0**
 Cylindrical keyless shaft and tapped hole **1**

BRAKE/SEAL OPTION
 Without brake or seal (no considered) **0**
 With brake (24 V DC), without seal **1**
 With brake (24 V DC), with seal **2**
 Without brake, with seal **3**

CONNECTION
 Interconnectron connector **0**

SPECIAL CONFIGURATION **S**

ESPECIFICATION **01 → ZZ**
 only when having the special "S" configuration !

FIGURE 6

Sales model of FS series axis feed motors.

MCSi-S0 SERVODRIVE

Introduction

The **MCS Innova** servo drive (MCSi) family is a compact speed servo drive family for controlling small synchronous AC brushless motors.

There are three modules of different power offering peak currents of 6.5, 10.5 and 15.0 Arms for single-phase 220 V AC.

General characteristics

Their main characteristics are:

- ❑ 220 V AC single-phase voltage supply.
- ❑ Dynamic braking in case of mains failure.
- ❑ PWM IGBTs.
- ❑ Serial encoder feedback.
- ❑ USB service communication line.
- ❑ Two logic inputs to control the motor: Speed Enable and Drive Enable.
- ❑ SERCOS communication protocol.

Dimensions




FIGURE 7

Dimensions of the MCSi-□□L-S0 drives.

Technical data

TABLE 8. Technical data.

	MODELS		
	MCSi 07L	MCSi 11L	MCSi 15L
Rated output current	2.1 Arms	3.5 Arms	5.0 Arms
Peak current (3 s)	6.5 Arms	10.5 Arms	15.0 Arms
Power supply	Single phase 50/60 Hz. Voltage range between 220 -10 % V AC and 230 +10 % V AC		
Consumption	12.5 Arms	20.0 Arms	29.0 Arms
Over-voltage protection	390 V DC		
Frequency	Lower than 600 Hz		
Internal Ballast resistor	-	-	45 Ω
Internal Ballast power	-	-	15 W
Ballast trigger	380 V DC		
Thermal protection of the heatsink	90 °C (194 °F)		
Operating temperature	5 °C / 45 °C (41 °F / 113 °F)		
Storage temperature	- 20 °C / 60 °C (- 4 °F / 140 °F)		
Protection degree *	IP 20		
Module dimensions	81x163.6x183 mm (3.18x6.44x7.20 ")	101x163.6x183 mm (3.97x6.44x7.20 ")	
Module mass	1.9 kg (4.18 lb)	2.1 kg (4.62 lb)	

* **IP 20** means that it is protected against objects of a diameter larger than 12.5 mm, but not against water splashes. Therefore, the unit must be mounted inside an electrical cabinet.

Connectors

Power terminals

CONNECTOR X4

POWER INPUTS L1, L2. Mains input terminals.

POWER OUTPUTS U, V, W. Output terminals for the voltage applied to the motor. Current control with PWM on a carrier frequency of 8 kHz. When connecting to the motor, watch the matching of phases U-U, V-V and W-W.

CONNECTOR X9

L+, Ri, Re. Terminals to configure and connect the external ballast resistor.

CONNECTOR X5

CONTROL POWER INPUTS L1, L2, GROUND. Input terminals for the voltage supply of the drive's control circuits from mains. The maximum cable section at these power terminals is 2.5 mm².

ACTIVATION OF THE INTERNAL FAN. The internal fan that cools the drive's power elements starts when enabling the Drive Enable signal. The fan will stop when the heat-sink temperature is lower 70 °C since the Drive Enable signal is turned off. This method decreases the fan's operating time, thus increasing its useful life.

Control signals

CONNECTOR X3

ENABLES

Drive Enable input, pin 13. No current circulates through the motor stator winding at 0 V DC, thus it no longer supplies torque. It is activated with +24 V DC.

Speed Enable input, pin 15. At 0 V DC, it forces an internal zero velocity command. It is activated with +24 V DC.

Common to inputs Drive Enable and Speed Enable, pin 14. Reference point for inputs Drive Enable and Speed Enable.

+24 V DC and 0 V DC, pins 43 and 44. Output of the internal 24 V DC power supply that may be used for the control of inputs Drive Enable and Speed Enable as well as the programmable digital input. It offers a maximum current of 50 mA limited internally.

pin 13	Drive Enable
pin 15	Speed Enable
pin 14	Pin common to inputs Drive Enable and Speed Enable
pin 43	+24 V DC of the auxiliary power supply (max. 50 mA)
pin 44	GND of the auxiliary 24 V DC power supply

DIGITAL INPUTS AND OUTPUTS

Programmable digital input, pins 11 and 12. Digital input (servo drive at +24 V DC and 0 V DC).

Programmable digital output, pins 27 and 28: Opto-coupled open collector output.

DRIVE OK.

Drive Ok, pins 29 and 30. Relay contact that closes when the internal status of the drive control is OK.

Note. Remember that this relay contact must be necessarily included in the electrical maneuver.

RELAY FOR SAFETY

Safe-disable relay, pins 41 and 42. Second, normally closed contact (NC) used as an external acknowledgement of the status of the safety relay.

Note. Remember that this relay contact must be necessarily included in the electrical maneuver.

CHASSIS

Metal housing of the connector. Drive chassis connection point.

CONNECTOR X2

MOTOR FEEDBACK INPUT (feedback Input)

Standard IEEE 1394 type connector for input of the serial encoder signals, installed on the motor itself for position + speed feedback.

CONNECTOR X6

SERVICE

Standard USB mini AB type connector for connecting to a PC and updating the firmware. Any standard USB cable with a miniA or miniB connector may be connected at the drive side.

CONNECTOR X7

SERCOS RING

Connector with two pins (IN and OUT) that may be used to connect the drive modules of the system with the CNC that governs them. The connection is made through fiber optic lines and it has a ring structure. It comes with two rotary switches and two status-indicating LED's (Light Emitting Diodes).

Indicators

+5 V. LED located on top of connector X1. When lit, it indicates that the internal +5V are being applied.

CROWBAR (ON) / VBUS OK. Two-color (green/red) light indicator located next to the +5 V LED. It indicates its status according to the following table:




FIGURE 8

"Crowbar (on) / VBus OK" LED states.

Module Status & Network Status. Indicator lights on top of the X1 connector above the two rotary "Node Select" selectors. It has several lighting sequences that indicate the status of both the SERCOS ring and the drive. For further detail, see section: Initialization and setup of this manual.


Numerical displays. It has four 7-segment numerical displays and a sign light to display the drive status.

Push-buttons and switches


RESET. Push-button for resetting the system.

NODE SELECT. Consisting in two rotary switches used to determine the node number assigned to the drive in the SERCOS ring and also select the communication speed and the light power of the SERCOS LED's. For further detail, see section: Initialization and setup of this manual.

Front view



Top view




Pinout of the connectors

FEEDBACK INPUT (X2)


Pin	Signal	Description
1	+ 5 V	Voltage supply for the encoder
2	GND	Encoder voltage supply GND
3	+ BAT	+ battery (with absolute encoder)
4	- BAT	- Battery (with absolute encoder)
5	+ 485	Encoder communication
6	- 485	Encoder communication
	Chassis	Connector housing

CONTROL SIGNALS (X3)




Pin	Signal	I/O	Description	
34	AUX. ± 12 V	O	+ 12 V (20 mA max) output	
33			- 12 V (20 mA max) output	
19			GND	
43	AUX 24 V DC	O	+ 24 V DC (50 mA max) output	
44			GND AUX 24 V DC	
13	DRIVE ENABLE	I	DRIVE ENABLE input (range from 0 to 24 V DC)	
15	SPEED ENABLE	I	SPEED ENABLE input (range from 0 to 24 V DC)	
14	COMMON DRIVE	-	Common to inputs DRIVE ENABLE and SPEED ENABLE	
11	PROG. DIGIT. INPUT	I	Programmable digital input +	Range from 0 to 24 V DC
12			Common of the digital input -	
27	PROG. DIGIT. OUTPUT	O	Programmable digital output (collector)	100 mA max, 50 V DC
28			Programmable digital output (emitter)	
29	DRIVE OK	O	Open contact of the DRIVE OK signal	
30			(0.6 A - 125 V DC, 0.5 A - 110 V DC, 2 A - 30 V DC)	
41	SAFETY RELAY	O	Second contact (N. C. normally closed) used as external acknowledgment of the status of the safety relay.	
42				

Out of the 44 pins of the connector, those not identified in this table are NC pins (Not Connected).
The < I/O > column indicates whether it is an input signal (Input) or an output signal (Output) through the relevant pin at connector X3.




POWER INPUTS & MOTOR (X4)

Pin	Signal	Description
L2	S phase	220 V mains voltage input terminals.
L1	R phase	
W	W phase	Output terminals for the voltage applied to the motor (200 V).
V	V phase	
U	U phase	




CONTROL POWER INPUTS (X5)

Pin	Signal	Description
L2	S phase	220 V mains input terminal for the control circuits.
L1	R phase	
	Chassis	Ground



SERVICE (X6)

Pin	Signal	Description
1	N. C.	Not connected
2	DMO	DMO
3	DPO	DPO
4	N.C.	Not connected
5	GND	GND
	Chassis	Housing



HONEYWELL RECEIVER-EMITTER (X7)

Pin	Signal	Description
IN	SERCOS (in)	SERCOS signal receiver
OUT	SERCOS (out)	SERCOS signal emitter

Sales model

Codes of the sales model of FAGOR MCS Innova drives with FAGOR SERCOS board.

MCS INNOVA DIGITAL DRIVE	EXAMPLE. MCSi - 07 L - S0												
Model MCS Innova _____	_____												
Current (A)	<table border="1" style="margin: auto;"> <thead> <tr> <th></th> <th>Rated</th> <th>Peak (3 s)</th> </tr> </thead> <tbody> <tr> <td>07</td> <td style="text-align: center;">2.1</td> <td style="text-align: center;">6.5</td> </tr> <tr> <td>11</td> <td style="text-align: center;">3.5</td> <td style="text-align: center;">10.5</td> </tr> <tr> <td>15</td> <td style="text-align: center;">5.0</td> <td style="text-align: center;">15.0</td> </tr> </tbody> </table>		Rated	Peak (3 s)	07	2.1	6.5	11	3.5	10.5	15	5.0	15.0
	Rated	Peak (3 s)											
07	2.1	6.5											
11	3.5	10.5											
15	5.0	15.0											
Power Supply 220 V AC _____	_____												
With SERCOS board _____	_____												

INSTALLATION

General considerations

At the motor

Remove the anti-corrosion paint of the rotor and of the flange before installing the motor on the machine. The motor may be mounted as IM B5 and IM V1.

Watch for the ambient conditions mentioned in the section on "technical data" and also:

- Mount it somewhere that is dry, clean and accessible for maintenance.


Note. The degree of protection is IP 55 (standard), shaft section excluded.

- It must be easily cooled.
- Avoid corrosive or flammable environments.
- Guard the motor with a cover if it is exposed to splashes.
- Use flexible coupling for direct transmission.
- Avoid radial and axial loads on the motor shaft.



MANDATORY. Do not hit the shaft when installing transmission pulleys or gears!

Use some tool that is supported in the threaded hole on the shaft to insert the pulley or the gear.



At the drive

The module must be installed in an electrical cabinet that is clean, dry, free of dust, oil and other pollutants. Remember that its degree of protection is IP 20.

Never install it exposing it to flammable gases. Avoid excessive heat and humidity. The ambient temperature must never exceed 45 °C (113 °F). Install the modules vertically, avoid vibrations and respect the gaps to allow air flow. See figure.




FIGURE 9

Module installing method.

About the connection

All the cables must be shielded, to reduce the interference on the control of the motor due to the commutation of the PWM.

The shield of the motor power cable must be connected to the chassis screw at the bottom of the module and it, in turn, taken to mains ground. The command signal lines must be shielded twisted pairs. The shield must be connected to the housing of connector X3.

Note. Keep the signal cables away from the power cables.

Electrical connections

Basic interconnection diagram




FIGURE 10

Basic module interconnection diagram.

Power connection. Mains-Drive

The drive is powered with single-phase 220 V AC.




FIGURE 11

Mains power connection of the drive, with transformer.

Note. It is required to install a transformer.




FIGURE 12

Mains power connection of the drive, without transformer.

The table below shows the values recommended for the fuses shown in the previous figure. They are slow general purpose fuses. If they are installed on the Mains input lines, their maximum currents will depend on the value of the Mains voltage.

TABLE 9. Fuses.

Model	Peak current (Arms)	Fuse (A)
MCSi-07L-S0	6.5	16
MCSi-11L-S0	10.5	16
MCSi-15L-S0	15.0	25

Note. A thermal switch may optionally replace the fuses.

Power connection. External Ballast resistor

If the application requires a Ballast resistor with a power greater than the one indicated in this table according to model:

TABLE 10. Ballast resistor.

Model	Internal resistor Ri		Max. power that may be dissipated in Ri	External resistor
MCSi-07L-S0	-	-	-	Max. value 65 Ω Min. value 45 Ω
MCSi-11L-S0	-	-	-	
MCSi-15L-S0	45 Ω	60 W	15 W	

therefore:

- Remove the cable joining the terminals Ri and L+.
- Install the external resistor between the terminals Re and L+.

- ❑ Make sure that the resistance (Ohms) of the external ballast resistor is the same as that of the internal resistor of that module. See **TABLE 8. Technical data.**
- ❑ Use KV41 to indicate to the drive that an external Ballast resistor has been connected.




FIGURE 13

Power connection for the external Ballast resistor.

Power connection. Inductance for reducing high frequency harmonics

It is recommended to connect an inductance at the input of one of the power phases **L1** or **L2** of the drive (connector X4) to reduce high frequency harmonics coming from mains with a value of 5 mH and and rms current of 6 Arms. This inductance reduces the disturbances in mains, but it does not ensure compliance with CE regulations. **Connect the inductance as shown in the figure.**

Power connection. Mains filter to suppress electromagnetic interference

In order for the Fagor DDS servo drive system to meet the European Directive on Electromagnetic Compatibility 2004/108/EC, the mains filter FAGOR FEHV-XXX must be inserted (see the table in the next section connection) **at the input of the MCSi (power phases L1 and L2 of connector X4)** against electromagnetic interference.

Connection

Install the proper filter that can handle the sum of the rated Arms currents of the MCSi drives installed in the system.

Mains filters	I _{max} (A)
FEHV-10Z	10
FEHV-16Z	16
FEHV-30B	30

Note. Remember that the rated currents of the drives are 2.1 A for the MCSi 07L-S0; 3.5 A for the MCSi 11L-S0 and 5 A for the MCSi 15L-S0.

Connect the filter using 6.3 mm Faston terminals as shown in the figure.




FIGURE 14

Power connection. Choque and mains filter.

Dimensions




FIGURE 15

Dimensions of the mains filter FAGOR FEHV-10Z/16Z.

Mains filters FAGOR FEHV- 30B




FIGURE 16

Dimensions of the mains filter FAGOR FEHV-30B.

Power connection. Drive-motor




FIGURE 17

Power connection between a motor (FSA/FSP 220 V) and MCSi-XXL-S0 drive.

Power cables

TABLE 11. Power cables.

For motors with brake	For motors without brake
MPC-4x0.5	MPC-4x0.5+(2x0.5)

Note. The length of the MPC power cable must be specifically ordered (in meters).

The code of the sales model of FAGOR power cables is:




FIGURE 18

Sales model of FAGOR power cables.

Connection of the monitoring and control signals

□ Enable signals using 24 V




FIGURE 19

Enable signals using 24 V.

□ Signal indicating that the Servodrive is running properly




FIGURE 20

Signal indicating that the Servodrive is running properly.

□ Enable signals




FIGURE 21

Enable signals.

□ Programmable digital outputs




FIGURE 22

Programmable digital outputs.

□ Programmable digital input




FIGURE 23

Programmable digital input.

Encoder feedback connection

The signals generated by the encoder are taken to connector (X2) FEEDBACK INPUT of the MCSi-XXL-S0 drive. The encoder must be mounted on to the motor shaft and cannot be installed anywhere else in the transmission chain.

Note. The motors may have use an incremental encoder J5 (13 bit) or an absolute encoder J7 (16 bit). But, when choosing an absolute encoder to use this characteristic, you must also obtain a battery with a mounting clip "Battery for Absolute Encoders in FS motor". The battery will not be necessary if you only wish to increase the resolution.

The connection cable is:




FIGURE 24

Encoder feedback connection cable.

Sales model of the FAGOR feedback cable

The sales model of the feedback cable is AESC-M-□□ where the last two digits shown as "□□" indicate its length in meters. For example the AESC-M-3 is a 3 meter encoder cable. The available lengths are: 1, 2, 3, 5, 7, 10, 15, 20, 25 and 30 meters.

Note. Remember that this encoder cable may be used both under static and dynamic work conditions.

Sales reference of FAGOR feedback extension cables

FAGOR also provides, upon request and in meters, the feedback cable (without connectors) with sales model **FSA/FSP Encoder Cable** up to 30 meters in case the user wants to make his own cable.

Service port. USB line

Connecting a PC compatible computer with an MCSi-XXL-S0 drive via USB (Universal Serial Bus) makes it possible to update the software and the motor table. The connection cable is a standard USB cable with a mini A or mini B type male connector at the drive side. The maximum length of the cable should not exceed 3 meters.

SERCOS ring connection

The SERCOS interface is an international standard for digital communications between CNC's and servo drives of CNC machines. This ring structure integrates different functions:

- It carries the velocity command from the CNC to the drive in digital format with greater accuracy and immunity against outside disturbances because the transmission takes place through a fiber optic cable.
- It transmits the feedback signal from the drive to the CNC.
- It communicates the errors and manages the basic control signals of the drive (enables).
- It allows setting, monitoring and diagnosis of the parameters from the CNC using simple standard procedures.

All this helps drastically reduce the amount of hardware required at the drive, thus making the system more reliable.

The different MCSi-XXL-S0 drive modules and the CNC are connected through the SERCOS Honeywell receiver-emitter of each of them (see the top side of the module) through the specific SERCOS fiber optic cable supplied by FAGOR.

Particular

Each ACSD-S0 has a NODE SELECT; in other words, their front panel has two 10-position (0-9) rotary switches for assigning a node number to each drive, an address that identifies and differentiates it within the SERCOS ring from the rest of the drives connected to it. This way, it is possible to assign values from 1 through 97 (both included) as identifiers (node number).

Values 98 and 99 can also be assigned; not as identifier, but as described next:

- NODE SELECT = 98** may be used to define the SERCOS power, i.e. the light power transmitted through the optical fiber.
- NODE SELECT = 99** may be used to set the transmission speed through the SERCOS ring.

For further detail, see section **Initialization and adjustment**.

Note. In order to make effective any changes on the NODE-SELECT rotary switches of the drive, the module must be RESET afterwards.



INFORMATION. Note that parameter DRIBUSID of the parameter table of each drive at the CNC must match the node number assigned to the drive using its two NODE-SELECT rotary switches.

Interconnection

Each drive to be governed by the CNC must be connected to the SERCOS ring through the SFO (Fiber optic) cable (see references later on) using the following procedure:

- ❑ Connect the OUT terminal of the first drive with the IN terminal of the next drive (adjacent to it).
- ❑ Repeat this procedure with the second drive, then with the third and so on up to the last drive.
- ❑ Now connect the OUT terminal of the last drive with the IN terminal of the CNC.
- ❑ Finally connect the OUT terminal of the CNC with the IN terminal of the first drive.

When all these connections have been made, the ring will be closed. See figure.




FIGURE 25

SERCOS ring connection.

Cabling




FIGURE 26

Fiber optic cable for SERCOS communication.

FAGOR supplies the fiber optic cable with its terminals protected with a hood. Remove the terminal protecting hood before connecting the cable. Either to remove the terminal protecting hood or to connect and disconnect the cable, the cable must always be held by the terminal, never pull at the cable because it could get damaged. See figure.




FIGURE 27

Handling of the fiber optic cable.




FIGURE 28

Sales models of FAGOR SERCOS fiber optic cables.

In connections with fiber optic cables up to 40 meters

When the optic fiber connection between the CNC and the drives does not exceed 40 meters, always use the SFO-FLEX cable if it is going to be under dynamic conditions (moving) and the SFO cable if it is going to be under static conditions (not moving). The useful life of the SFO-XX cable will not be guaranteed when installed under dynamic operating conditions.

Reference	Minimum bending radius (under static conditions)	Minimum bending radius (under dynamic conditions)
SFO	30 mm	-
SFO-FLEX	50 mm	70 mm

In connections with fiber optic cables over 40 meters

If the fiber optic connection between the CNC and the drives exceeds 40 meters, always use the SFO-V-FLEX cable.

Reference	Minimum bending radius (under static conditions)	Minimum bending radius (under dynamic conditions)
SFO-V-FLEX	45 mm	60 mm

Diagram of the electrical cabinet

Here is an example of a connection diagram for the electrical cabinet that may be modified depending on the needs of each application. It includes a simple circuit for the voltage supply of the brake of the servo motors.



MANDATORY. The use of fuses is a must.

Mains connection and maneuver diagram

The delayed disconnection of KA3 contacts is useful so:

- The Drive Enable stays active while the motor brakes at maximum torque.
- The brake holds the motor after it has stopped (only on vertical axes).




FIGURE 29

Diagram of the maneuver. See also [FIGURE 11](#) and [FIGURE 12](#).

Safety. Safe Disable

The Safe Disable function (SD) offered by FAGOR MCSi-XXL-S0 drives permits disabling the power output of the drive making sure that the motor torque is eliminated as a safe situation.

This function is available through the "Drive Enable" section so called in standard Fagor servo drive systems. Techniques and elements approved to be used in safety systems have been considered for its design and internal operation.

Thus, with a conventional drive (without SD), a contactor would have to be installed to assure a safe disable of the motor. However, using the safety techniques (implemented in Fagor MCSi-XXL-S0 drives) guarantees the same or greater safety without having to use external contactors, thus saving material and room in the electrical cabinet.




FIGURE 30

Block diagram of the safety circuit.

For that, a safety relay with guided contacts has been considered so:

- The first contact (N.O.) enables the power inverter and sets the control part to rest assuring a redundancy when locking up.
- The second contact (N.C.) is used as an external acknowledgement of the status of the safety relay. This contact is available between pins 41 and 42 of connector X3 located on the face of the module.

The following figure shows the diagram of the safe disable (SD) of an MCSi-XXL-S0 and as an example of application, a diagram to control the access to areas with moving elements.




FIGURE 31

Safety relay and access control diagram with moving elements.

The diagram to control the access to areas with moving elements is:




FIGURE 32

Diagram to control the access with moving elements.

Initialization and adjustment

The system can only be initialized and adjusted using the SERCOS ring (only means of communication offered by the MCSi-XXL-S0 drive). This process is carried out from the master device (CNC).

Note. Remember that the USB serial line can only be used to transfer the software to the drive.



INFORMATION. To update the software version of the MCSi-XXL-S0 drive, the CNC must be disconnected. If this condition is not met, the user must re-set it with a <SHIFT+RESET> once the software has been loaded.

Initially, bear in mind the elements that make up each drive in order to configure the communication with the master device. These elements are:

NODE SELECTION. <NODE SELECT>

Two rotary switches identified on the face plate of the MCSi-XXL-S0 with the labels (x1, x10) used to set the node number assigned to the drive in the SERCOS ring. The node number must be selected before starting up the drive, otherwise it will only be valid after restarting and resetting the drive again. Node numbers 1 through 97 (both included) are valid as address identifiers. Node 0 must always be assigned to the master device.


Nodes 98 and 99 must be used to define the light power transmitted through the fiber optic cable (SERCOS power) and to set the transmission speed in the ring, respectively.

COMMUNICATION SPEED SELECTION

The transmission speeds shown in the following table may be selected when using SERCOS interface:

TABLE 12. Transmission speeds with SERCOS interface.

Node Select "x1"	Transmission speed	
1	2 MBd	
2	4 MBd	
3	8 MBd	
4	16 MBd	



NODE=99

How is the SERCOS ring transmission speed selected?

The transmission speed selecting mode is activated when starting up any unit and whenever both rotary switches x1 and x10 of the NODE SELECT are set to 9 (selecting node 99). From this state, now, to:

❑ **Verify the selected transmission speed.**

To know the communication speed at the ring at that very instant, turn the rotary selector "x1" of the NODE SELECT to the "0" position. The NS indicator LED will blink red and it will then turn off for about 1 second. It will repeat this sequence indefinitely.

The number of blinks between the off intervals indicates the communication speed according to **TABLE 12.**; Thus, for example, 3 blinks between two OFF intervals of the NS LED will mean that the communication speed is 8 MBd at that very instant.

❑ **Select a new baudrate.**

To **SELECT** the communication speed of the unit, turn the rotary selector switch "x1" of the NODE SELECT to position 1, 2, 3 or 4 depending on the associated transmission speed according to **TABLE 12.**; the NS indicator LED will blink green showing the speed that has been selected.

Note. When selecting a value higher than 4 at the "x1" selector, it will assume a value of 4.

Once the transmission speed is selected, it must be CONFIRMED. Turn the "x10" rotary switch to position zero. The MS indicator LED will turn red and the selected speed will be saved in the "non-volatile" memory of the unit.


From this moment on, after the unit is turned on, it will assume as the transmission speed the last one confirmed before turning it on.

SELECTING THE LIGHT POWER TRANSMITTED THROUGH OPTICAL FIBER

It will set the light power to be transmitted through the optical fiber depending on cable length.

TABLE 13. Transmission speeds with SERCOS interface.

Node Select "x1"	Fiber optic cable length L (in meters)
1, ..., 4	$L < 15$
5, 6	$15 \leq L < 30$
7	$30 \leq L < 40$
8	$L \geq 40$



NODE=98

How is the SERCOS ring transmission light power selected?

The transmission light power selecting mode is activated when starting up any unit and whenever the x1 rotary switch of the NODE SELECT is set to 9 and the x10 is set to 9 (selecting node 98).

From this state, now, to:

Verify the selected light power and/or select a new one, use the same procedure followed in the previous section for selecting the transmission speed. Note that for this case, the possible number of blinks between off intervals of the NS LED is 8. See **TABLE 13.** to interpret the equivalence between the number of blinks and the light power transmitted depending on the length of the cable being used.

MS INDICATOR LED. <MODULE STATUS>

This indicator light informs about the unit status as such. The states that may be currently reached are:

TABLE 14. Indicator Led **Module Status.**

MS LED status	Meaning
Steady green LED	The drive is error and warning free
Blinking green LED	The drive is in a warning state
Blinking red LED	The drive is in an error state

NS INDICATOR LED. <NETWORK STATUS>

This light indicator informs about the phase the SERCOS ring is in and whether there are distortions or not. The phase will be indicated by the number of LED blinks and the distortions by the LED color. The states that may be currently reached are:

TABLE 15. Indicator Led **Network Status. Phases.**

NS LED status	Meaning
Steady LED	Drive in phase 0. No activity in the SERCOS ring or the master device has not been able to close the communication ring.
One blink	Drive in phase 1. The master device is locating and identifying each and every drive connected to the SERCOS ring.
Two blinks	The service channel is on. Here are defined the communications parameters for the following stages and the data to be transmitted through the cyclic channel.
Three blinks	Drive in phase 3. State prior to normal operation. Defining more parameters required for the drive to operate.
Four blinks	Drive in phase 4. Normal operation.

TABLE 16. Indicator Led **Network Status. Distortions.**

NS LED color	Meaning
Green	Lack of distortions.
Red	Lack of distortions. The counter that counts distortion errors indicating the number of times that a distortion error has come up in phase 4 of SERCOS communication has exceeded the value of 100.

PARAMETERS, VARIABLES & COMMANDS

The parameters, variables and commands of the drive that are shown next may be used with any device that works as master. Besides all these, there are others that may be used to communicate the drive with the CNC.

Notation used

GROUP	TYPE	INDEX
-------	------	-------

where:

GROUP. Identifying character of the logic group to which the parameter or variable belongs. There are the following groups of parameters:

TABLE 17. Groups of parameters, variables and commands.

Nr	Function	Group	Letter
1	Operating mode	Application	A
2	Control signals	Terminal box	B
3	Current control loop	Current	C
4	Error diagnosis	Diagnosis	D
5	General of the system	General	G
6	System hardware	Hardware	H
7	Analog and digital inputs	Inputs	I
8	Temperatures and voltages	Monitoring	K
9	Motor properties	Motor	M
10	Mechanical elements	Mechanical	N
11	Analog and digital outputs	Outputs	O
12	Position control loop	Position	P
13	System communication	SERCOS communication	Q
14	Velocity control loop	Speed	S
15	Torque and power parameters	Even	T

TYPE. Character identifying the type of data which the information corresponds to. May be:

- Parameter (P) defining the system operation.
- Variable (V) that can be read and modified dynamically.
- Command (C) that carries out a specific action.

INDEX. Number identifying the parameter or the variable within the group to which it belongs.

Definition examples:

Mnemonic	Group	Type	Index
SP10	S	(P) Parameter	Nr 10
CV11	C	(V) Variable	Nr 11
GC1	G	(C) Command	Nr 1

ACCESS LEVEL. The access level is defined by the number following the ID SER-COS. Thus:

- FAGOR level (1)
- USER level (2)
- BASIC level (3)

Examples of access levels

	Group	Type	Index	Access	Type of variable
SP10 BASIC	S	(P) Parameter	Nr 10	Basic	-
CV11 FAGOR, RO	C	(V) Variable	Nr 11	Fagor	(RO) Read Only

MODIFIABLE VARIABLE. Any modifiable variable, in other words, that can be read and written, will carry the (RW) label to identify it as such next to its access level. The (RO) label means that the variable is Read Only.

Note. All the parameters have the (RW); i.e. they can be read and written.

Example of a modifiable variable

	Group	Type	Index	Access	Type of variable
DV32 FAGOR, RW	D	(V) Variable	Nr 32	FAGOR	(RW) Read-Write

PARAMETER THAT CANNOT BE MODIFIED WITH TORQUE. Any parameter that for any reason cannot be modified while the unit has torque will have an asterisk (*) identifying it as such next to its access level.

Example of a parameter that cannot be modified with torque

	Group	Type	Index	Access	* RW
MP1 BASIC, *RW	M	(P) Parameter	Nr 1	Basic	Example of read and write, but cannot be modified with torque.

A group. Application

AP1	USER, RW	S00032	PrimaryOperationMode
------------	-----------------	---------------	-----------------------------

Function. It sets how it works in terms of system configuration.

Valid values. 2. Velocity command (without position loop).

B group. Non-programmable inputs-outputs

BV14	FAGOR, RO	F00204	NotProgrammableIOs
-------------	------------------	---------------	---------------------------

Function. Indicates the logic values of the electrical signals of the drive's control. 24 V at the electrical input mean a logic 1 at the bits of this variable.

Bit	Function
15, ..., 4	Reserved
3	Programmable input Pins 11 and 12 of terminal strip X3
2	"Drive OK" output Pins 29 and 30 of terminal strip X3
1	Speed Enable input Pin 15 of terminal strip X3
0	Drive Enable input Pin 13 of terminal strip X3

C group. Current

CP1	*FAGOR, RW	S00106	CurrentProportionalGain
------------	-------------------	---------------	--------------------------------

Function. Value of the proportional action of the current PI.

Valid values. 0, ..., 999.

Default value. Depends on the motor-drive combination.

CP2	*FAGOR, RW	S00107	CurrentIntegralTime
------------	-------------------	---------------	----------------------------

Function. Value of the integral action of the current PI.

Valid values. 0, ..., 999.

Default value. Depends on the motor-drive combination.

CP20	*BASIC, RW	F00307	CurrentLimit
-------------	-------------------	---------------	---------------------

Function. Limit of the current command that reaches the system's current loop.

Valid values. 0.00, ..., 50.00 Arms. CP20 must never exceed the smallest value given by the peak current of the motor (5 x MP3) and of the drive.

Default value. CP20 takes the lowest value of the ones given by the motor and drive peak currents.

CP30	FAGOR, RW	F00308	CurrentCommandFilter1Type
-------------	------------------	---------------	----------------------------------

Function. Parameter in charge of enabling / disabling the current filter.

Valid values. 1/0. Enables/disables the current filter.

Default value. 0. Current filter disabled.

CP31	FAGOR, RW	F00312	CurrentCommandFilter1Frequency
-------------	------------------	---------------	---------------------------------------


Function. Sets the natural frequency in Hz of a notch filter that acts upon the current command.

Valid values. 0, ..., 4 000 Hz.

Default value. 0.

CP32	FAGOR, RW	F00313	CurrentCommandFilter1Damping
-------------	------------------	---------------	-------------------------------------

Function. Sets the bandwidth in Hz of a notch filter that acts upon the current command.



Valid values. 0, ..., 1 000 Hz.

Default value. 0.

CV1	USER, RO	F00309	Current1Feedback
------------	-----------------	---------------	-------------------------

Function. Display the value of the feedback of the current going through phase V.

Valid values. - 50.00, ..., 50.00 A (instant values).


CV2	USER, RO	F00310	Current2Feedback
------------	-----------------	---------------	-------------------------

Function. Display the value of the feedback of the current going through phase W.

Valid values. - 50.00, ..., 50.00 A (instant values).

CV3	USER, RO	F00311	CurrentFeedback
------------	-----------------	---------------	------------------------

Function. Display the rms current circulating through the motor.



Valid values. - 50,00, ..., 50,00 A (rms values).

CV10	FAGOR, RO	F00305	Current1Offset
-------------	------------------	---------------	-----------------------

Function. Value of the automatic compensation of the current feedback offset of phase V.

Valid values. -2.000, ..., 2.000 A (depends on the connected drive).

CV11	FAGOR, RO	F00306	Current2Offset
-------------	------------------	---------------	-----------------------

Function. Value of the automatic compensation of the current feedback offset of phase W.

Valid values. -2.000, ..., 2.000 A (depends on the connected drive).

D group. Diagnosis

DV1	BASIC, RO	S00011	Class1Diagnostics (Errors)
------------	------------------	---------------	-------------------------------------

Function. Variable that contains a numerical data coded into 16 binary bits and represents the error status as shown by the attached table.

Bit	Name	Error
0	OverloadShutdown	E.201, E.202, E.314
1		
2	MotorOvertempShutdown	E.108
3	CoolingErrorShutdown	E.106
4		
5	FeedbackError	E.801, E.802
6		
7	OverCurrentError	E.214
8	OverVoltageError	E.304
9	UnderVoltageError	E.307
10	PowerSupplyPhaseError	E.003
11		
12	CommunicationError	E.400 → E.499
13		
14		
15	ManufacturerSpecificError	Rest.

DV9	BASIC, RO	S00012	Class2Diagnostics (Warnings)
------------	------------------	---------------	-------------------------------------

Function. Variable that contains a numerical data coded into 16 binary bits and represents the warning status as shown by the attached table.

Bit	Name	Warning
0	OverloadShutdown	A000 caused by:
		201 Motor overload
		202 Drive overload
		314 Ballast overload

DV17	USER, RO	F00410	HistoricOfErrors
-------------	-----------------	---------------	-------------------------

Function. Stores the last 5 errors that came up at the drive. It consists in a 5-word register that stores the code of each one of them.

Valid values. All the codes of the list of possible errors of the software version currently loaded. Code 0 means no error.

DV18	BASIC, RO	F02105	DisplayError
-------------	------------------	---------------	---------------------

Function. Variable that may be used to display the code of an error that comes up at the drive. If no errors come up, its value will be zero.

DV19	BASIC, RO	F02106	DisplayWarning
-------------	------------------	---------------	-----------------------

Function. Variable that may be used to display the code of a warning that comes up at the drive. If no warnings come up, its value will be zero.

DV31	FAGOR, RO	S00135	DriverStatusWord
-------------	------------------	---------------	-------------------------

Function. Variable that contains a numerical data coded into 16 binary bits and represents the system status in certain aspects as shown by the attached table. This variable communicates with the CNC through the SERCOS interface.

Bits	Meaning
15, 14	Power & Torque Status (0,0)DoingInternalTest(DRVSTS_INITIALIZING) (0,1) ReadyForPower (DRVSTS_LBUS) (1,0) PowerOn (DRSTS_POWER_ON) (1,1) TorqueOn (DRSTS_TORQUE_ON)
13	Error bit.
12	Warning bit
11	0
10, 9, 8	= 0, PrimaryOperationMode
7	Real time status bit
6	Real time status bit
5, 4, 3, 2, 1, 0	Reserved

DV32	FAGOR, RW	S00134	MasterControlWord
-------------	------------------	---------------	--------------------------

Function. Variable that contains a numerical data that in 16-bit binary code represents the control signals that the CNC sends to the drive through the SERCOS interface. See attached table. This variable communicates with the CNC through the SERCOS interface.

Bits	Name
15	Speed Enable (SPENA)
14	Drive Enable (DRENA)
13	Halt
12, 11, 10	Reserved
9, 8, 7, 6, 5	Reserved
4, 3, 2, 1, 0	Reserved

DC1	USER, RW	S00099	ResetClassDiagnostics
------------	-----------------	---------------	------------------------------

Function.

Reset of the unit's errors. When an error occurs, this command may be used to reset it and restart the unit by first updating the error bit of DV31, DriveStatusWord, and then setting the drive in the ReadyForPower state. Note its difference with the unit's reset because the action carried out by this command **keeps the RAM memory intact** and therefore the parameter settings of the unit.

DC2	USER, RW	F00402	ClearHistoricOfErrorsCommand
------------	-----------------	---------------	-------------------------------------

Function.

Reset of the "DV17 (F00410) HistoricOfErrors (array)" variable. This command sets it to 0.

G group. General

GP1	BASIC, RW	F00700	PwmFrequency
-----	-----------	--------	--------------

Function. It returns the switching frequency of the transistors.

Valid values. 0, ..., 8 000 Hz.

Default value. 8 000 Hz.

GP3	BASIC, RW	F00702	StoppingTimeout
-----	-----------	--------	-----------------

Function. After deactivating the Speed Enable and after the GP3 time has elapsed, if the motor has not stopped, it cancels the torque automatically and issues error E.004. If the motor stops within the GP3 time, it also cancels the torque but does not issue an error. To make this time infinite (never generating error E.004), set this parameter to "0".

Valid values. 1, ..., 9 999 ms, 0 (infinite).

Default value. 500 ms.

GP4	BASIC, RO	F00703	SetNumber
-----	-----------	--------	-----------

Function. Number of sets of useful parameters.

Valid values. 0/1.

Default value. Always 1. A single set.

GP5	BASIC, RO	F00704	ParameterVersion
-----	-----------	--------	------------------

Function. This parameter represents the version of the parameter table that has been loaded at the drive.

Valid values. 0, ..., 9 999.

GP6	BASIC, RW	F00717	GearRatioNumber
-----	-----------	--------	-----------------

Function. Number of useful gear ratios.

Valid values. 0, ..., 8

Default value. Always 1. A single gear ratio.

GP9	BASIC, RW	S00207	DriveOffDelayTime
-----	-----------	--------	-------------------

Function. After the motor has stopped because the Speed Enable function has been disabled, the cancellation of the the Drive Enable function (that implies PWM-OFF) is delayed by a time period indicated by GP9. It is useful on axes not compensated with a holding brake.

To make this time period infinite, set it to 0 and to remove it, set it to 1.

Valid values. 1, ..., 9 999 ms, 0 (infinite).

Default value. 50 ms.

GV2	BASIC, RO	S00030	ManufacturerVersion
------------	------------------	---------------	----------------------------

Function. Displays the software version in use.

Valid values. 0, ..., 9 999.

GV5	BASIC, RO	F00706	CodeChecksum
------------	------------------	---------------	---------------------

Function. It registers the checksum value of the software version loaded at the drive.

Valid values. - 32 768, ..., 32 767 (although the range goes up to 65 535 because it is a 16-bit variable).

GV6	BASIC, RO	F00723	RamParameterChecksum
------------	------------------	---------------	-----------------------------

Function. It informs on the checksum of the parameters contained in RAM memory.

Valid values. 0, ..., 65 535.

GV8	FAGOR, RW	F00707	AccessLevel
------------	------------------	---------------	--------------------

Function. It informs about the current access level of the user.

Valid values.
 1. BASIC
 2. OEM (User)
 3. FAGOR

GV9	BASIC, RO	S00140	DriveType
------------	------------------	---------------	------------------

Function. This variable informs of the drive's sales model.

GV11	BASIC, RW	F00708	SoftReset
-------------	------------------	---------------	------------------

Function. Variable that resets the unit by software.

GV16	BASIC, RO	F00716	MotorTableVersion
-------------	------------------	---------------	--------------------------

Function. Version of the motor table.

GV26	BASIC, RW	S00218	GearRatioPreselection
-------------	------------------	---------------	------------------------------

Function. It determines which will be the active gear ratio (software) when the change is carried out via SERCOS.

Valid values. Always 0. Gear ratio 0.

GC1	BASIC, RW	S00264	BackupWorkingMemoryCommand
------------	------------------	---------------	-----------------------------------

Function. Command to execute the parameter transfer from RAM to E²PROM.

GC10	BASIC, RW	S00262	LoadDefaultsCommand
-------------	------------------	---------------	----------------------------

Function. Command to initialize parameters. This command loads the default drive parameters for a motor that has been previously selected with parameter MP1.

H group. Hardware

HV1	BASIC, RO	S00110	DrivePeakCurrentSercos
------------	------------------	---------------	-------------------------------

Function. Peak rms current of the drive.

Valid values. 0.00, ..., 50.00 A.

HV5	BASIC, RO	F00295	PLDVersion
------------	------------------	---------------	-------------------

Function. Software version installed in the unit's PLD's

I group. Inputs

IP6	USER, RW	F00910	DigitalInputPolarity
------------	-----------------	---------------	-----------------------------

Function. Sets the polarity (inverted or not inverted) of the programmable digitalinput (pins 11 and 12 of X3).


Valid values. 0/1. Not inverted/inverted.

Default value. 0. Not inverted.

IV10	USER, RO	F00907	DigitalInputs
-------------	-----------------	---------------	----------------------

Function. This variable reflects the status of the programmable digital input at pins 11-12 of connector X3. The status of this variable is affected by IP6.

Valid values. 0 and 1.



K group. Monitoring

KP3	USER, RW	F01114	ExtBallastPower
------------	-----------------	---------------	------------------------

Function. Contains the value of power of the external ballast resistor.

Valid values. 200, ..., 2000 W.

Default value. 200 W.

KP4	USER, RW	F01116	ExtBallastEnergyPulse
------------	-----------------	---------------	------------------------------

Function. Contains the value of the energy pulse that can be dissipated by the external ballast resistor.

Valid values. 200, ..., 2000 J.

Default value. 200 J.

KV10	USER, RO	F01102	CoolingTemperature
-------------	-----------------	---------------	---------------------------

Function. It displays the temperature of the heatsink of the power stage.

Valid values. 0, ..., 200 °C.

KV32	USER, RO	F01109	I2tDrive
-------------	-----------------	---------------	-----------------

Function. Variable internally useful to the system. It measures the internal load level of the calculation of the i^2t at the drive in percentage used over the maximum.

Valid values. 0, ..., 100 %.

KV36	USER, RO	F01111	I2tMotor
-------------	-----------------	---------------	-----------------

Function. Variable internally useful to the system. It measures the internal load level of the calculation of the i^2t at the motor in percentage used over the maximum.

Valid values. 0, ..., 100 %.

KV40	USER, RO	F01115	I2tCrowbar
-------------	-----------------	---------------	-------------------

Function. Shows the load percentage on the ballast resistor in a drive. Useful for the i^2t protection of the resistor. A value greater than 100 % in this variable causes error E.314.

Valid values. 0, ..., 100 %.

KV41	USER, RW	F01117	BallastSelect
-------------	-----------------	---------------	----------------------

Function. Selector that determines whether the ballast resistor is external or internal.

Valid values: 0/1. External/internal (by default).

M group. Motor

MP1	BASIC, RW	S00141	MotorType
------------	------------------	---------------	------------------

Function. Motor identification. The limits of certain parameters depend on the value of MP1 (e.g.: The upper limit of SP10 is 110 % of the motor rated speed) like its default parameter initialization through GC10. See command [GC10](#).

MP2	FAGOR, RW	F01200	MotorTorqueConstant
------------	------------------	---------------	----------------------------

Function. Contains the torque constant of the synchronous motor, (motor torque according to the rms current)

Valid values. 0.00, ..., 10.00 N·m/Arms.

MP3	FAGOR, RW	S00111	MotorContinuousStallCurrent
------------	------------------	---------------	------------------------------------

Function. Contains the motor rated current. Manipulating MP3 may affect parameter CP20 directly. See parameter [CP20](#).

Valid values. 0.00, ..., 50.00 Arms. Depends on the motor connected.

MP4	FAGOR, RO	S00109	MotorPeakCurrent
------------	------------------	---------------	-------------------------

Function. Contains the motor peak current. This current value must NEVER be exceeded in the motor. See parameter [CP20](#).

Valid values. 0.00, ..., 50.00 Arms. Depends on the motor connected.

Default value: It depends on the motor connected.

N group. Mechanical

NP116	USER, RO	S00116	ResolutionOfFeedback1
--------------	-----------------	---------------	------------------------------

Function. Parameter that cannot be modified by the user that "tells" the CNC the number of pulses of the motor feedback.

Valid values. 1, ..., 65 535.

NP121	USER, RW	S00121	InputRevolutions
--------------	-----------------	---------------	-------------------------

NP122	USER, RW	S00122	OutputRevolutions
--------------	-----------------	---------------	--------------------------

Function. They define the gear ratio between the motor shaft and the final axis moved by the machine. For example, if 5 turns of the motor shaft mean 3 turns of the machine leadscrew, the value of these parameters is NP121=5 and NP122=3.

Valid values. 1, ..., 32767 turns

Default value. 1 turn in both parameters (direct coupling).

NP123	USER, RW	S00123	FeedConstant
--------------	-----------------	---------------	---------------------

Function. It defines the gear ratio between the linear movement of the machine and the axis moving it. For example, if every turn of the leadscrew means a 4 mm displacement of the table, the value for this parameter is NP123=4.

For a rotary axis NP123=360, which means 360° per turn.

Valid values. 0, ..., 2 147 483 647.

O group. Analog and digital outputs

OP6	USER, RW	F01416	DigitalOutputPolarity
------------	-----------------	---------------	------------------------------

Function. Sets the polarity (inverted or not inverted) of the programmable digital input (pins 27 and 28 of X3).


Valid values. 0/1. Not inverted (by default) / inverted.

Default value. 0. Not inverted.

OV10	USER, RO	F01410	DigitalOutputs
-------------	-----------------	---------------	-----------------------

Function. The OV10 variable contains the value of the status of the programmable digital output. The programmable digital output is activated (with a 1) or deactivated (with a 0) via SERCOS (see pins 27-28 of X3).

Valid values. 0 (activate programmable digital output) and 1 (deactivate programmable digital output).



P group. Position loop

PP52	USER, RW	S00052	ReferenceDistance1
-------------	-----------------	---------------	---------------------------

Function. With motor feedback, this parameter describes the distance between the machine reference zero and the machine reference point.

Valid values. - 214 748.3648, ..., 214 748.3647 (mm for linear axes or degrees for rotary axes).

PP55	USER, RW	S00055	PositionPolarityParameters
-------------	-----------------	---------------	-----------------------------------

Function. 16-bit register that may be used to invert the sign of the various position data.

Bit	Function
2	Sign of the value of the motor feedback. = 0, Not inverted = 1, Inverted (by default)

PP76	USER, RW	S00076	PositionDataScalingType
-------------	-----------------	---------------	--------------------------------

Function. 16-bit register that configures the measuring scale for the positioning.

Bit	Function
15 (MSB), 14, 13, 12, 11, 10, 9, 8 (reserved)	= 0
7	Format: = 0, absolute = 1, module. See parameter PP103 . Note. Verify that the CNC defines the axis the same way (module or linear format).
6	The position command refers to: = 1, The position of the load. ALWAYS !
5, 4, 3, 2	Reserved
1, 0 (LSB)	Position command scaling method. = 01, Linear scaling (by default) = 10, rotary scaling

PP103	USER, RW	S00103	ModuleValue
--------------	-----------------	---------------	--------------------

Function. Module value. If bit 7 of PP76 selects the module format, this parameter defines the range of the position data being used.

Valid values. 0, ..., 214 748.3648 (mm for linear axes or degrees for rotary axes).

Default value. 360°. Normally used on rotary axes.

PP150	BASIC, RW	S00150	ReferenceOffset1
--------------	------------------	---------------	-------------------------

Function. Parameter that gives the position of the machine reference point with respect to the reference mark (I0), depending on motor feedback.

Valid values. - 214 748.3648, ..., 214 748.3647 (mm for linear axes or degrees for rotary axes).

Default value. 0.0000.

PP177	BASIC, RW	S00177	AbsoluteDistance1
--------------	------------------	---------------	--------------------------

Function. For motors with absolute encoder, this parameter indicates the distance between the zero coordinate of the drive and the theoretical zero coordinate according to the absolute encoder feedback.

Valid values. - 214 748.3648, ..., 214 748.3647 (mm for linear axes or degrees for rotary axes).

Default value. 0.0000.

PV51	USER, RO	S00051	PositionFeedback1
-------------	-----------------	---------------	--------------------------

Function. Motor feedback position that is transferred to the CNC.

Valid values. - 214 748.3648, ..., 214 748.3647 (mm for linear axes or degrees for rotary axes).

PV173	USER, RO	S00173	MarkerPositionA
--------------	-----------------	---------------	------------------------

Function. In the home searching process, when the drive detects the I0 signal, it saves the value of the PositionFeedback1 (not yet homed) in this variable.

Valid values. - 214 748.3648, ..., 214 748.3647 (mm for linear axes or degrees for rotary axes).

Default value. 0.0000.

PV175	BASIC, RW	S00175	DisplacementParameter1
--------------	------------------	---------------	-------------------------------

Function. Offset of the coordinate system after the home search carried out by the drive (with motor feedback).

Valid values. - 214 748.3648, ..., 214 748.3647 (mm for linear axes or degrees for rotary axes).

Default value. 0.0000.

PV203	BASIC, RW	S00403	PositionFeedbackStatus
--------------	------------------	---------------	-------------------------------

Function. The drive activates this binary variable to inform that it interprets the position feedback as being referred to the machine reference zero point. The variable is canceled when executing the home search command and is activated when the execution ends successfully.

Valid values. 0. Position data referred to any point.
 1. Position data referred to machine zero.
Default value. 0.

PV204	BASIC, RW	S00404	PositionCommandStatus
--------------	------------------	---------------	------------------------------

Function. Variable internally useful to the system. It indicates whether the position command is referred to machine reference zero or not.

Valid values. 0. Not referred to machine reference zero.
 1. Referred to machine zero.

Default value. 0.

PV207	BASIC, RW	S00407	HomingEnable
--------------	------------------	---------------	---------------------

Function. Enabling of the Homing function.

Valid values. 0. Home search disabled.
 1. Home search enabled.

Default value. 0.

PC146	USER, RW	S00146	NCControlledHoming
--------------	-----------------	---------------	---------------------------

Function. Homing function controlled by CNC.

Q group. Communication

QP1	USER, RW	S00001	ControlUnitCycleTime
------------	-----------------	---------------	-----------------------------

Function. Read parameter that indicates every how long the drives close the loop. Therefore, it defines the loop time.

Valid values: 2, ..., 8 ms.

Default value. 4 ms.

QP11	BASIC, RW	F02000	SercosMbaud
-------------	------------------	---------------	--------------------

Function. It sets the transmission speed through the SERCOS ring. The CNC has a similar parameter with SERCOS interface.

Both speeds (at the CNC and at the drive) must be the same in order to establish communication.

Valid values. 2, 4, 8 and 16 Mbd.

Default value. 4 Mbd.

QP12	BASIC, RW	F02002	SercosTransmisiónPower
-------------	------------------	---------------	-------------------------------

Function. It defines the SERCOS power, i.e. the light power transmitted through the optical fiber.

Valid values. 1, ..., 8.

Value	Fiber optic cable length L (in meters)
1, ..., 4	$L < 15$
5, 6	$15 \leq L < 30$
7	$30 \leq L < 40$
8	$L \geq 40$

Default value. 2.

QV30	USER, RO	F00727	FiberDistErrCounter
-------------	-----------------	---------------	----------------------------

Function. This variable may be used to diagnose SERCOS problems. It is a counter that counts distortion errors indicating the number of times that a distortion error has come up in phase 4 of SERCOS communication.

Valid values. 0, ..., 65 535.

S group. Velocity

SP1	BASIC, RW	S00100	VelocityProportionalGain
------------	------------------	---------------	---------------------------------


SP2	BASIC, RW	S00101	VelocityIntegralTime
------------	------------------	---------------	-----------------------------

Function. Value of the proportional / integral action of the velocity PI.

Valid values. SP1: 0, ..., 999.9 mArms/rpm.

SP2: 0, ..., 999.9 ms.

Default value. Depends on the motor-drive combination.



SP3	BASIC, RW	S00102	VelocityDerivativeGain
------------	------------------	---------------	-------------------------------

Function. Value of the derivative action of the velocity PI.

Valid values. SP3: 0, ..., 9 999.


Default value. SP1: 0.

SP10	BASIC, RW	S00091	VelocityLimit
-------------	------------------	---------------	----------------------

Function. Maximum velocity limit for SV7 (VelocityCommandFinal).

Valid values. 0, ..., 110 % motor rated speed in rev/min.

Default value. 1000 rev/min.



SP42	USER, RW	S00124	StandStillWindow
-------------	-----------------	---------------	-------------------------

Function. Determines the value of the velocity window around zero that will be considered to be zero speed.

Valid values. 0, ..., motor rated speed in rev/min.


Default value. 20 rev/min.

SP43	BASIC, RW	S00043	VelocityPolarityParameters
-------------	------------------	---------------	-----------------------------------

Function. This parameter is used to change the sign of the velocity command in specific applications. It cannot be used to solve a positive feedback problem (axis runaway).

Valid values. 0/1. Not inverted / inverted.

Default value. 0. Not inverted.




SP60	BASIC, RW	S00138	AccelerationLimit
-------------	------------------	---------------	--------------------------

Function. Determines the value of the acceleration ramp applied to the velocity command. Setting this parameter with a zero value means that no ramps will be applied.


Valid values. 0.0, ..., 400.0 (rev/min)/ms.

Default value. 0.0.



SP65	BASIC, RW	F01609	EmergencyAcceleration
-------------	------------------	---------------	------------------------------

Function. In emergency stop. If the bus voltage drops or there is a power outage for the unit in the acceleration, deceleration or constant power mode, the drive will get into the dynamic braking sequence. It stops with the emergency ramp until its speed is zero as long as the mechanical energy stored in the motor allows it. Therefore, it limits the command acceleration for stopping the motor. If anytime during the sequence, the Drive Enable is interrupted, the motor will turn by inertia. SP65=0 cancels this limiting effect.



Valid values. 0.0, ..., 400.0 (rev/min)/ms.


Default value. 0.0.

SP66	BASIC, RW	F01618	VelocityDecelerationTime
-------------	------------------	---------------	---------------------------------

Function. Determines the value of the deceleration ramp applied to the velocity command. Setting this parameter with a zero value means that no ramps will be applied.

Valid values. 0.0, ..., 400.0 (rev/min)/ms.

Default value. 0.0.



SV1	BASIC, RW	S00036	VelocityCommand
------------	------------------	---------------	------------------------

Function. Velocity command.

Valid values. - 4 950.0000, ..., 4 950.0000 rev/min.

SV2	BASIC, RO	S00040	VelocityFeedback
------------	------------------	---------------	-------------------------

Function. Velocity feedback.

Valid values. - 6 000.0000, ..., 6 000.0000 rev/min.

SV6	BASIC, RO	F01622	VelocityCommandAfterFilters
------------	------------------	---------------	------------------------------------

Function. Velocity command after applying limits, ramps, etc.

Valid values. - 6 000.0000, ..., 6 000.0000 rev/min.

SV7	BASIC, RO	F01612	VelocityCommandFinal
------------	------------------	---------------	-----------------------------

Function. Final velocity command applied to the loop.

Valid values. - 6 000.0000, ..., 6 000.0000 rev/min.

T group. Torque and power


TV1	USER, RO	S00080	TorqueCommand
-----	----------	--------	---------------

TV2	USER, RO	S00084	TorqueFeedback
-----	----------	--------	----------------

Function. Displays the values of the command and torque feedback.

Valid values. - 999.9, ..., 999.9 N·m.

Default value. 0.0 N·m.



ERROR CODES

E.001	Internal
--------------	-----------------



Contact Fagor Automation.

E.003	With torque, the power bus drops
--------------	---




Error.

When having torque; probably, one of the three-phase lines has dropped.

Warning.

When starting the unit up, maybe:

- The connector of the Ballast resistor has not been installed.
- The Ballast resistor is open.



Solution.


Verify that the lines and the drives are in good condition and restart the system.

E.004	Emergency stop exceeding time limit GP3
--------------	--



An attempt has been made to stop the motor by canceling Speed Enable. The system has tried to stop the motor at full torque, but it has not been able to stop it in the time frame set by parameter GP3 (StoppingTimeout = maximum time allowed for braking, before considering the error for being unable to stop it in the set time) or

If $t1 < GP3$, then after GP9, MOTOR TORQUE ON = 0;
else, MOTOR TORQUE ON = 0 and E.004



the parameter that determines when the motor is considered to be stopped (SP42) Minimum velocity threshold, is too small.

Bear in mind that zero speed (total lack of velocity) does not exist, there is always a minimum amount of speed noise due to feedback.

Solutions.

The load that must stop the motor is too large to stop it in the time frame set by GP3 and the value given to this parameter must be increased.

The threshold or velocity window considered zero (SP42) is too small; thus, increase the value of this parameter.

The module is performing poorly and is unable to stop the motor. The module may be defective.

E.106	Extreme temperature at the heatsink of the IGBT's	E.106
--------------	--	--------------

The drive is carrying out a task that overheats the power devices.

Solution.

Stop the system for several minutes and decrease the effort demanded from the drive.

E.108	Motor overheated	E.108
--------------	-------------------------	--------------


The motor has overheated. The motor temperature measuring cables (position sensor cable) or the temperature sensor itself are defective. The application may be demanding high current peaks.

Solution.

Stop the system for several minutes and decrease the effort demanded from the drive. Cool the motor.

E.200	overspeed	E.200
--------------	------------------	--------------


The motor speed has exceeded the value of SP10 in a 12 %.
Bad cabling of the position sensor or of the motor power or the velocity loop is adjusted wrong.



Solution.

Decrease the speed overshoot in the system response.

E.201	Motor overload	E.201
--------------	-----------------------	--------------



The I2t protection of the motor has been activated.
The duty cycle is greater than the motor can provide.

Solution


Decrease the duty cycle.

E.202	Drive overload	E202
--------------	-----------------------	-------------

The I2t protection of the drive has been activated. The duty cycle is greater than the system can provide.

Solution.

Decrease the speed overshoot in the system response.



E.214	Short-circuit	E214
--------------	----------------------	-------------

There is short-circuit at the drive module.

Solution.

Reset the error.

If it persists, may be because:

- An erroneous sequence when connecting the power cables or a short-circuit between them.
- Wrong parameters or malfunction at the drive.

Solution.

Contact Fagor Automation.

After displaying E.214, one of the codes of the following table will be displayed. The drive where the alarm has been detected is:

ABS	Over the absolute value of the output current
IGBT	At the IGBT's
OUT	At the output

E.304	Drive's power bus voltage too high	E304
--------------	---	-------------

The hardware of the drive module has detected that the voltage at the power bus is too high.

With external Ballast, maybe the connection is wrong or the Ballast resistor is defective.

Solution.

Disconnect the power supply and check the proper connection of the Ballast circuit.

E.307	Power bus voltage too low	E.307
--------------	----------------------------------	--------------

The mains voltage is lower than the required minimum voltage.

Solution.

Disconnect the power supply and check the proper condition of the lines.

E.314	Ballast overload	E.314
--------------	-------------------------	--------------

Due to the duty cycle, the Ballast resistor is overloaded.

Solution.

- Resize the Ballast resistor.
- Decrease the duty cycle.
- Smooth the duty cycle by applying acceleration ramps.

E.403	MSTfault	E.403
--------------	-----------------	--------------

E.404	MDTfault	E.404
--------------	-----------------	--------------

E.405	Err_InvalidPhase	E.405
--------------	-------------------------	--------------

E.406	Err_PhaseUpshift	E.406
--------------	-------------------------	--------------

E.407	Err_PhaseDownshift	E.407
--------------	---------------------------	--------------

The errors of the 400 series refer to various communication problems through the fiber optic ring.

Check the ring connections and the identification of each module.

E.410	SERCON reset due to noise	E.410
--------------	----------------------------------	--------------

Noise entering the drive and causing the RESET of the SERCON but not of the drive.

E.411	Error indicating telegram received. Is wrong	E.411
--------------	---	--------------

E.412	SERCOS synchronism error	E.412
--------------	---------------------------------	--------------

The master device (CNC) sends a synchronism message in every cycle (usually every 4 ms) that synchronizes the drives.

If they cannot be synchronized or lose their synchronism, it causes this error. Maybe the CNC has not sent this message or if it has, it did it at the wrong time.

Check the transmission cable or verify that the transmission is not noisy.

E.502	Incompatible parameters	E.502
--------------	--------------------------------	--------------

Parameter incompatibility.

Example.

A drive controls a motor that admits a peak current of 20 A (e.g.: being the current limit CP20=20 A). If now, a 16A peak motor is connected, the current limit will be beyond the value allowed for this new motor. It will readjust in RAM memory certain parameters related to speed and current issuing E.502. Resetting the unit without saving the parameters causes the error to come up again. The error will go away when executing the GC1 command because the parameters readjusted to the right values by the drive in RAM memory are saved in E²PROM memory:

E.506	Motor table missing	E.506
--------------	----------------------------	--------------

Contact Fagor Automation.

E.510	Incoherent combination of motor and feedback	E.510
--------------	---	--------------

Motor not accepted by the drive. Motor's power voltage is different from that of the drive.

E.801	Encoder not detected	E.801
--------------	-----------------------------	--------------

The drive has not detected the rotor sensor.

Solution.

Check the cabling and the motor connection regarding connector X2. Then do a RESET.

If it doesn't fix it, contact Fagor Automation.

E.802	Defective encoder	E.802
--------------	--------------------------	--------------

Communication error. After an initial connection, communication errors keep coming up.

Solution

Check the cabling and the motor connection regarding connector X2. Then do a RESET.

If it doesn't fix it, contact Fagor Automation.

LIST OF PARAMETERS, VARIABLES & COMMANDS. SERCOS ID's

Mnem.	Name	Level	ID SERCOS	Acc.	Min.	Max.	Def.	Units	Page
AP1	PrimaryOperationMode	USER	S00032	RW	1	13	-	-	44
BV14	NotProgrammableIOs	FAGOR	F00204	RO	0	65535	-	-	44
CP1	CurrentProportionalGain	FAGOR	S00106	RW	0	999	-	-	45
CP2	CurrentIntegralTime	FAGOR	S00107	RW	0	999	-	-	45
CP20	CurrentLimit	BASIC	F00307	RW	0	50,00	0	A	45
CP30	CurrentCommandFilter1Type	FAGOR	F00308	RW	0	1	0	-	45
CP31	CurrentCommandFilter1Frequency	FAGOR	F00312	RW	0	4000	0	Hz	45
CP32	CurrentCommandFilter1Damping	FAGOR	F00313	RW	0	1000	0	Hz	45
CV1	Current1Feedback	USER	F00309	RO	- 50.00	50.00	-	A	46
CV2	Current2Feedback	USER	F00310	RO	- 50.00	50.00	-	A	46
CV3	CurrentFeedback	USER	F00311	RO	- 50.00	50.00	-	A	46
CV10	Current1Offset	FAGOR	F00305	RO	- 2.000	2.000	-	A	46
CV11	Current2Offset	FAGOR	F00306	RO	- 2.000	2.000	-	A	46
DC1	ResetClass1Diagnostics	USER	S00099	RW	0	15	0	-	49
DC2	ClearHistoricOfErrorsCommand	USER	F00402	RW	0	15	0	-	49
DV1	Class1Diagnostics (Errors)	BASIC	S00011	RO	0	65535	-	-	47
DV9	Class2Diagnostics (Warnings)	BASIC	S00012	RO	0	65535	-	-	47
DV17	HistoricOfErrors	USER	F00410	RO	0	999	-	-	47
DV18	DisplayError	BASIC	F02105	RO	0	65535	-	-	47
DV19	DisplayWarning	BASIC	F02106	RO	0	65535	-	-	48
DV31	DriverStatusWord	FAGOR	S00135	RO	0	65535	-	-	48
DV32	MasterControlWord	FAGOR	S00134	RW	0	65535	-	-	48
GC1	BackupWorkingMemoryCommand	BASIC	S00264	RW	0	15	0	-	51
GC10	LoadDefaultsCommand	BASIC	S00262	RW	0	15	0	-	51
GP1	PwmFrequency	BASIC	F00700	RO	0	8000	8000	-	50
GP3	StoppingTimeout	BASIC	F00702	RW	0	9999	500	ms	50
GP4	SetNumber	BASIC	F00703	RO	0	1	1	-	50
GP5	ParameterVersion	BASIC	F00704	RO	0	9999	-	-	50
GP6	GearRatioNumber	BASIC	F00717	RW	0	8	1	-	50
GP9	DriveOffDelayTime	BASIC	S00207	RW	0	9999	50	ms	50
GV2	ManufacturerVersion	BASIC	S00030	RO	0	9999	-	-	51
GV5	CodeChecksum	BASIC	F00706	RO	- 32768	32767	-	-	51
GV6	RamParameterChecksum	BASIC	F00723	RO	0	65535	-	-	51
GV8	AccessLevel	FAGOR	F00707	RW	1	3	-	-	51
GV9	DriveType	BASIC	S00140	RO	- 32768	32767	-	-	51
GV11	SoftReset	BASIC	F00708	RW	0	16	-	-	51
GV16	MotorTableVersion	BASIC	F00716	RO	0	32767	-	-	51
GV26	GearRatioPreselection	BASIC	S00218	RW	0	7	-	-	51
HV1	DrivePeakCurrentSercos	BASIC	S00110	RO	0	50,00	-	A	52
HV5	PLDVersion	BASIC	F00295	RO	0	65535	-	-	52
IP6	DigitalInputPolarity	USER	F00910	RW	0	1	-	-	52
IV10	DigitalInputs	USER	F00907	RO	0	1	-	-	52
KP3	ExtBallastPower	USER	F01114	RW	200	2000	200	W	53
KP4	ExtBallastEnergyPulse	USER	F01116	RW	200	2000	200	J	53
KV10	CoolingTemperature	USER	F01102	RO	0	200	-	°C	53
KV32	I2tDrive	USER	F01109	RO	0	100	-	%	53
KV36	I2tMotor	USER	F01111	RO	0	100	-	%	53
KV40	I2tCrowbar	USER	F01115	RO	0	100	-	%	53
KV41	BallastSelect	USER	F01117	RW	0	1	1	-	53
MP1	MotorType	BASIC	S00141	RW	- 32768	32767	-	-	54
MP2	MotorTorqueConstant	FAGOR	F01200	RW	0	10,00	-	N·m/A	54
MP3	MotorContinuousStallCurrent	FAGOR	S00111	RW	0	50,00	-	A	54
MP4	MotorPeakCurrent	FAGOR	S00109	RO	0	50,00	-	A	54
NP116	ResolutionOfFeedback1	USER	S00116	RO	0	65535	-	-	55

Mnem.	Name	Level	ID SERCOS	Acc.	Min.	Max.	Def.	Units	Page
NP121	InputRevolutions	USER	S00121	RW	1	32767	1	-	55
NP122	OutputRevolutions	USER	S00122	RW	1	32767	1	-	55
NP123	FeedConstant	USER	S00123	RW	0	2147483647	-	-	55
OP6	DigitalOutputPolarity	USER	F01416	RW	0	1	-	-	56
OV10	DigitalOutputs	USER	F01410	RO	0	1	-	-	56
PC146	NCControlledHoming	USER	S00146	RW	0	3	-	-	59
PP52	ReferenceDistance1	USER	S00052	RW	-214748.3648	214748.3647	-	mm or °	57
PP55	PositionPolarityParameters	USER	S00055	RW	0	65535	-	-	57
PP76	PositionDataScalingType	USER	S00076	RW	1	65535	-	-	57
PP103	ModuleValue	USER	S00103	RW	0	214748.3647	360	mm or °	57
PP150	ReferenceOffset1	BASIC	S00150	RW	-214748.3648	214748.3647	0	mm or °	58
PP177	AbsoluteDistance1	BASIC	S00177	RW	-214748.3648	214748.3647	0	mm or °	58
PV51	PositionFeedback1	USER	S00051	RO	-214748.3648	214748.3647	-	mm or °	58
PV173	MarkerPositionA	USER	S00173	RO	-214748.3648	214748.3647	0	-	58
PV175	DisplacementParameter1	BASIC	S00175	RW	-214748.3648	214748.3647	0	mm or °	58
PV203	PositionFeedbackStatus	BASIC	S00403	RW	0	1	0	-	58
PV204	PositionCommandStatus	BASIC	S00404	RW	0	1	0	-	59
PV207	HomingEnable	BASIC	S00407	RW	0	1	0	-	59
QP1	ControlUnitCycleTime	USER	S00001	RW	2	8	4	ms	60
QP11	SercosMbaud	BASIC	F02000	RW	0	16	4	Mbd	60
QP12	SercosTransmissionPower	BASIC	F02002	RW	1	8	2	-	60
QV30	FiberDistErrCounter	USER	F00727	RO	0	65535	-	-	60
SP1	VelocityProportionalGain	BASIC	S00100	RW	0	999,9	-	mArms/rpm	61
SP2	VelocityIntegralTime	BASIC	S00101	RW	0	999,9	-	ms	61
SP3	VelocityDerivativeGain	BASIC	S00102	RW	0	9999	0	-	61
SP10	VelocityLimit	BASIC	S00091	RW	0	9999	1000	rev/min	61
SP42	StandStillWindow	USER	S00124	RW	0	9999	20	rev/min	61
SP43	VelocityPolarityParameters	BASIC	S00043	RW	0	1	0	-	62
SP60	AccelerationLimit	BASIC	S00138	RW	0	400.0	0	rpm/ms	62
SP65	EmergencyAcceleration	BASIC	F01609	RW	0	400.0	0	rpm/ms	62
SP66	VelocityDecelerationTime	BASIC	F01618	RW	0	400.0	0	rpm/ms	63
SV1	VelocityCommand	BASIC	S00036	RW	-4950.0000	4950.0000	0	rev/min	63
SV2	VelocityFeedback	BASIC	S00040	RO	-6000.0000	6000.0000	-	rev/min	63
SV6	VelocityCommandAfterFilters	BASIC	F01622	RO	-6000.0000	6000.0000	-	rev/min	63
SV7	VelocityCommandFinal	BASIC	F01612	RO	-6000.0000	6000.0000	-	rev/min	63
TV1	TorqueCommand	USER	S00080	RO	-999.9	999.9	0	Nm	64
TV2	TorqueFeedback	USER	S00084	RO	-999.9	999.9	-	Nm	64

FAGOR AUTOMATION S. COOP.

B.º San Andrés Nº 19

Apdo de correos 144

20500 Arrasate-Mondragón

- Spain -

Web: www.fagorautomation.com

Email: info@fagorautomation.es

Tel.: (34) 943 719200


Fax: (34) 943 791712



Fagor Automation S. Coop.


VELOCITY CONTROL BLOCK DIAGRAM

DISPLAY	DRIVE STATUS
L. buS	Waiting P. Supply
[.]	Drive ready
[rdy1]	Motor running
[rdy0]	Motor running speed = 0
[rdy~]	Drive Enable "on" and no pulses



ERROR	DESCRIPTION
E.001	Watch dog
E.003	Power Supply fault / warning
E.004	Stop time > GP3
E.106	Drive overtemp
E.108	Motor overtemp
E.200	Overspeed
E.201	I2t motor
E.202	I2t drive
E.214	Short-circuit
E.304	Bus overvoltage
E.307	Bus low voltage
E.314	I2t Ballast
E.403	MSTfault
E.404	MDTfault
E.405	Err_InvalidPhase
E.406	Err_PhaseUpshift
E.407	Err_PhaseDownshift
E.410	SERCON reset due to noise
E.411	Error indicating telegram received. Wrong
E.412	SERCOS synchronism error
E.502	Incompatible parameters
E.506	Motor table missing
E.510	Incoherent combination of motor & feedback
E.801	Encoder not detected
E.802	Defective encoder

MP1 WITH FEEDBACK TYPE
F5 INCREMENTAL ENCODER: 13 bits (2048 ppt)
F7 ABSOLUTE ENCODER: 16 bits (16384 ppt)



X2 CONNECTOR
MOTOR SENSOR INPUT


MOTOR SERIES				
MOTOR LENGTH	LONG MOTORS A SHORT MOTORS P			
SIZE/POWER				
HEIGHT	FSA		FSP	
	LFe	200V kW	200V	kW
60	28	02 0.2		
	56	04 0.3 0.4		
	80	08 0.65 0.75		
80	20		02 0.2	
	40		04 0.4	
120	28		08 0.75	
MAXIMUM SPEED				
50 5000 rev/min Note that rated speed is 3000 rev/min				
VOLTAGE				
200 V F				

FSA04.50F.J5.000 - S99


SPECIFICATION	01 → ZZ
only when having the special "S" configuration !	
SPECIAL CONFIGURATION	S
CONNECTION	0
Interconnection connector	
BRAKE/SEAL OPTION	
Without brake or seal (not considered)	0
With brake (24 V DC), without seal	1
With brake (24 V DC), with seal	2
Without brake, with seal	3
EJE Y BRIDA	
Cylindrical shaft with keyway and tapped hole	0
Cylindrical keyless shaft and tapped hole	1
FEEDBACK	
13 bit incremental	J5
16 bit absolute	J7

ERROR FUNCTIONS


Function E.003 Power Supply fault




Function E.106 Drive overtemp




Function E.200 Overspeed



Function E.201 Motor overload



Function E.202 Drive overload



Function E.314 Ballast overload

KV41	1	Internal Ballast resistor
KV41	0	External Ballast resistor

